

Easy-To-Install Flooring

In four lightning-fast steps, you can have your surface fully installed in minutes or less.

Getting Started

The panels have two sides with female PowerLock®, and two sides with male PowerLocks. All tiles on any given installation should **always** have the female PowerLocks going in the same direction.



Female PowerLock



Male PowerLock

Step One

Begin the installation by laying down your first panel in any one corner and pointing the female PowerLocks in the two directions that additional panels are to be added.



Step Two

Place the next panel so that the male PowerLock line up over the top of the female loops on the first panel. It's important to make sure that the female PowerLock are facing exactly the same direction as the first panel.



Step Three

Gently step along the joint of the two panels. You will hear and feel the PowerLock® snap into place as you go.



Step Four

Once the two panels are joined, repeat steps one through three remembering to keep the female PowerLocks aligned until your floor is complete.



That's all there is to this easy-to-install flooring!